



User Manual

Ipad Active Capacitive Pen



Note: The picture is for reference only, the appearance is subject to the actual

Product Details



- ① Touch switch
- ② Type-C charging port
- ③ ABC Indicator light
- ④ Detachable nib

Product parameter


Model NO: Active capacitive pen
Material: metal Paint
Anti-mis-touch function: Yes
Input: 5V-0.1A
Tilt pressure feeling: Yes
Bluetooth: No
Pen head: Replaceable pen head
Applicable model:
ipad 2018 (version6)
ipad 2019 (version7)
ipad 2020 (version8)
ipad 2021 (version9)
ipad 2022 (version10)
ipad mini (version5)
ipad mini (version6)
ipad Air(version3)
ipad Air(version4)
ipad Air(version5)
ipad Pro(11 inches)
ipad pro11 inches(version2)
ipad pro11 inches(version3)
ipad pro11 inches(version4)
ipad Pro12.9 inches(version3)
ipad pro12.9 inches(version4)
ipad pro12.9 inches(version5)
ipad pro12.9 inches(version6)
The model can be confirmed on the back of the IPAD device. Other models are invalid.

Product Features

- Stylish and minimalist style, aluminum alloy with piano baking varnish, calm and luxurious, novel and durable.
- Replaceable nib design, no fear of wear and tear! New upgraded tilt and thickening function, the larger the pen tilt area, the thicker the line.
- The tip of the pen is made of special conductive materials and finely ground. Artificially create a smooth pen tip to prevent damage to the screen.
- Products compatible with iPad 2018 after model (specific model to see product parameters) can be written, painted, recorded
- Continuous use for up to 8-10 hours (for reference only), 5 minutes without using smart power off


How to Use

- Double-click the top of the capacitive pen to power on, the indicator light is on to start using, touch again The top of the capacitive pen is turned off twice, and the indicator light is off.




Tap the power on and off twice

- With magnetic adsorption function, it can be adsorbed by lightly putting it on, like Apple Pencil can be adsorbed on the tablet.




- Detachable and replaceable nib design, no need to worry about wear and tear! (Lightly twist the nib for easy removal/ installation)




(Disassembly) (install)

How to Charge


- Please use micro usb/Type-C charging cable to charge, and connect one end to the usb interface of stylus and the other end to the USB interface of computer or tablet. (FIG 1)
- Please connect one end of the data cable to the pen and the other end to the 5V DC power adapter.(FIG 2)
- Directly plug the 5V mobile power supply with usb interface into the stylus to charge. During the charging process, the indicator light will light up, and the whole charging time is about 90 minutes.(FIG 3)



(FIG 1)



(FIG 2)



(FIG 3)

Battery reminder

jobs	A light is on	Battery level 5%-30%
	AB light is on	Battery level 30%-70%
	ABC light is on	Battery level 70%-100%
Lowpower	A light flashes	Battery is less than 5%
	A light flashes	Battery level 5%-30%
Recharge	A light is on, B light flashes	Battery level 30%-70%
	AB light is on, C light flashes	Battery level 70%-95%
full	ABC light is on	More than 95% battery

Instructions for use

- iPad version is not lower than 12.2;
- Open Settings-Apple Pencil-Turn off only use Apple Pencil to doodle
- Turn on Settings-Bluetooth and close the connection of the original Apple Pen. (After the above settings are completed, the product can be used normally.)

